How to install the driver for the USB-RS232 cable on a 32 or 64bit system (XP, Vista, Seven, windows 8 & 10)

ATTENTION: For this operation, it is necessary to have the "administrator" rights.

a) Don't connect the USB-RS232 cable before installing the driver

b) Download the USB-RS_CH340.zip file from www.elc.fr and uncompress it, preferably on the desktop.

A directory is created named "USB-RS_CH340"
It contains the file "CH340SER.EXE".
Run this program (double-click), which will create a directory named: C: \ WCH.CN \ CH341SER, with all the drivers (.inf & .sys files).

c) Connect the lead to one of the USB ports. If the following message appears:
"The device can not install" Open "Device Manager", Search for the location with « ! »
(Unknown Device).

Right-click and update the driver

Choose the option "Search & install the driver manually"
Paste the search location: C: \ WCH.CN \ CH341SER

The installation must succeed and the pilot will be present in :
Device Manager> Ports (COM & LPT)
under the name: USB-SERIAL CH340

Details of the driver files.

System 32bits (XP)

System 64bits (Seven)